

# EV Accessories Parcel Shelf Lifter

Thank you for choosing to shop with EV Accessories. We hope you find your purchase useful and value for money.

## Installation Instructions.

Your Model S parcel shelf is installed as show below in Figure 1. The lifter set uses a friction fit to lift the shelf. In reality only one is required, but it looks far better with two and improve reliability.

## Tools Required.

- A small or medium flat bladed screw driver or blunt table knife.
- insulation tape if desired.

If you have plastic trim tool that would be perfect. But this is not something most people have, if you have kids with a plastic tea set, reach for one of the knives, they really are perfect for the job.

Figure 1

1. Wrap the screw driver or knife tip with a small amount of insulation tape if you feel it's needed to prevent and damage to the trim. We didn't use any but we recommend you do.
2. Open the boot and lift the parcel shelf so it rests in the open position, you know the one where you forget to put the parcel shelf back and it restricts your rear-view mirror vision.
3. Insert your tool into the **gap A** as show in fig 1, this will open the trim slightly to enable you to insert the red end of the lift in to the gap. You only need to insert about 1cm in to the gap. Basically, just hide the red end. Position the chord into position B on Fig1. and then repeat on the opposite side.



4. Now lift the shelf to fix the Velcro to the underside of the shelf as show in C, then repeat on the other side.
5. If you need to remove the parcel shelf in future simply remove the Velcro and the parcel shelf will come out. Remove the Velcro slowly and no to lift the material on the shelf.

If you place objects on the shelf that are too heavy, the lifter cords will pull out as to not damage the trim. If you find it pulls out to easily simply tie a knot in the red end and re-insert into the Gap. This may be needed depending on how well your boot trim fits.